



Setting up PSCAD v5.0.1 Update 3

This document provides instructions for setting up PSCAD v5.0.1 Update 1 (v5.0.1.3).

Note

If v5.0.1 (v5.0.1.0 or v5.0.1.1 or v5.0.1.2) is already installed, running this installation will replace your earlier build.

Release Notes

The release notes for this version are posted to this [article](#).

System Requirements

System requirements for this version are posted to this [article](#).

Obtaining Access to the Update

If the update is not available in your MyCentre user account, you may request the download from our sales desk sales@pscad.com. Please ensure to include your PSCAD license number in your request.

Instructions

Set up PSCAD v5.0.1 Update 3 as follows:

- a. Log in to [MyCentre](#), and download and unzip the software.
The contents will be a zipped file (*.zip).
- b. Unzip the file, and save this to a local location on your machine (e.g. desktop).
- c. From the unzipped file, launch “setup.exe”, and select the option to elevate, then:
 - If an earlier v5.0.1 build is already installed, select the option *Repair* when prompted.
 - For detailed or quick start setup instructions, please refer as follows:
 - If using certificate licensing, refer to this [article](#)
 - If using lock-based licensing, refer to this [article](#)
- d. If using the Intel Fortran compiler with Visual Studio 2015 or later, PSCAD must be reconfigured to use the libraries as per Step 2 of this [article](#) after the installation.

We hope this helps to set up PSCAD v5.0.1 Update 3. If there are any questions, please contact our [support desk](#).

Copyright © 2022 Manitoba Hydro International Ltd. All Rights Reserved.