



## Setting up PSCAD v5.0.2 Update 1

This document provides instructions for setting up PSCAD v5.0.2 Update 1 (v5.0.2.1).

### Note

If v5.0.2 (initial) is already installed, running this installation will replace your earlier build.

### Release Notes

The release notes for this version are posted to this [article](#).

### System Requirements

System requirements for this version are posted to this [article](#).

### Obtaining Access to the Update

If the update is not available in your MyCentre user account, you may request the download from our sales desk [sales@pscad.com](mailto:sales@pscad.com). Please ensure to include your PSCAD license number in your request.

### Instructions

Set up PSCAD v5.0.2 Update 1 as follows:

- a. Log in to [MyCentre](#), and download and unzip the software.  
The contents will be a zipped file (\*.zip).
- b. Unzip the file, and save this to a local location on your machine (e.g. desktop).
- c. From the unzipped file, launch "setup.exe", and select the option to elevate, then:
  - If v5.0.2 is already installed, select the option **Repair** when prompted.
  - For detailed or quick start setup instructions, please refer as follows:
    - If using certificate licensing, refer to this [article](#)
    - If using lock-based licensing, refer to this [article](#)
- d. If using the Intel Fortran compiler with Visual Studio 2015 or later, PSCAD v5.0.2 Update 1 must be configured to use the libraries as per Step 2 of this [article](#) after the installation.

We hope this helps to set up PSCAD v5.0.2 Update 1. If there are any questions, please contact our [support desk](#).